

# SMARTair™ System overview – Update on Card

## Required hardware and software



PC, software and card encoder



Wall updater



User credentials




SMARTair™ devices

## Features

- Medium to high user traffic, automatic control
- Update access rights via user cards
- Wall updater is the link between software and doors
- Scheduled access rights possible
- Automatic read-out of audit trails
- Low battery alert report
- Wall-Updater: TCP/IP connection to database, Read & Write functionality with 13.56Mhz credentials

### Your door requirements



### How to update access rights

